HERBRAND

Herbrand Tools

HERBRAND DIVISION, THE BINGHAM-HERBRAND CORP.
FREMONT, OHIO

EFFECTIVE DATE AUG. 1, 1960

MECHANICS' NET

AUTOMATIC TRANSMISSION TOOLS

Tool Number	Price Each	Description	Page
AT-3	$14.05	Oil Pressure Gauge	11
AT-5	18.98	Hydramatic Universal throttle Arm Bending tool	9
AT-6	1.56	Power Glide Hexagon Adaptor	10
AT-7	2.71	Throttle Valve stop Bending tool	2
AT-8	3.39	Tru-Arc #2 Pliers	6
AT-20	1.16	Rear Servo Gauge	6
AT-21	10.74	Hydramatic Universal Throttle Arm Gauge	9
AT-22	14.90	Throttle Lever Protractor Gauge	2
AT-23	4.55	1954 Ford Linkage Gauge	2
AT-24	3.40	1951-53 Ford Linkage Gauge	2
AT-25	.82	Ford Gage Block	3
AT-50	11.47	Hydramatic Adjusting Tool	5
AT-51	10.30	Dynaflow & Powerglide Ext. Adj. Tool	10
AT-52	24.70	Ford Rear Band Adj. Tool	3
AT-53	11.33	Ford Front Band Adj. Tool	3
AT-54	7.20	Front Servo Adj. Tool	6
AT-55	11.47	Powerflite reverse Band Adj. Tool	11
AT-56	19.52	Powerflite Kickdown Adj. Tool	11
**AT-60	5.99	Internal Snap Ring Pliers	8
**AT-61	5.99	External Snap Ring Pliers	8
AT-70	1.45	Hydramatic Throttle Linkage Pin	11
AT-71	.46	Ford Throttle Linkage Pin	3
AT-76	14.40	Clutch Spring Compressor	7
AT-77	15.25	Front & Rear Clutch Tester	7
*AT-78	37.37	Dial Indicator (In Metal Container)	4
AT-79	1.73	Dial Indicator Extension Rod	5
AT-80	1.99	Ford Dial Indicator Rod	4
AT-81	12.38	Rear Servo Spring Compressor	8
AT-82	5.71	Mainshaft Snap Ring Remover	8
AT-83	6.85	Oil Delivery Sleeve Compressor	8
*AT-84	12.38	Small Seal Puller	7
AT-90	39.88	Seal Driver Set	4
AT-91	20.09	Powerglide Bushing Remover & Installer Set	12
AT-92	25.85	Dynaflow Bushing Installer & Remover Set	12
AT-93	26.42	Hydramatic Bushing Driver Set	9
AT-94	19.67	Fordomatic-Mercomatic Bushing Remover & Installer Set	

** Used for serving more than one model of Automatic Transmission* ***Special Discounts*

SEE REVERSE SIDE FOR PRICES ON DISPLAY BOARDS AND INDIVIDUAL PIECES WHICH COMPRISE THE VARIOUS SETS.

Form No. AT 4005

	Tool Number	Price	Description
	185	$ 5.00	Lock Ring Plier
	186	3.89	Lock Ring Plier
	866T	8.85	Slide Hammer with T-Handle
SET NO. AT-78	AT-78-1	18.31	Gauge
	AT-78-2	3.80	Horizontal Rod Assembly
	AT-78-3	3.80	Horizontal Rod Assembly
	AT-78-4	1.27	Vertical Rod
	AT-78-5	3.80	"C" Clamp Assembly
	AT-78-6	5.37	Deep Hole Attachment—Long
	AT-78-7	6.31	Swivel Bracket Assembly
SET NO. AT-90	AT-90-1	2.59	Front Pump Seal Driver
	AT-90-2	4.22	Front Pump Seal Driver
	AT-90-3	3.05	Output shaft seal driver
	AT-90-4	3.05	Output shaft seal driver
	AT-90-5	7.19	Front pump seal driver
	AT-90-6	7.88	Front pump seal driver
	AT-90-7	8.00	Adapter Driver
SET NO. AT-91	AT-91-1	4.32	Driver Handle
	AT-91-2	3.28	Adapter (Powerglide trans. rear bushing remover)
	AT-91-3	2.82	Adapter (Powerglide trans. rear bushing installer)
	AT-91-4	2.13	Adapter (Powerglide clutch bushing)
	AT-91-5	2.76	Adapter (Powerglide front pump bushing)
SET NO. AT-92	AT-92-1	5.98	Driver Handle
	AT-92-2	3.17	Adapter (Dynaflow trans. case bushing)
	AT-92-3	2.60	Adapter (Dynaflow front pump bushing)
	AT-92-4	9.32	Adapter (Dynaflow reaction flange bushing)
SET NO. AT-93	AT-93-1	5.58	Adapter (Front pump bushing)
	AT-93-2	5.35	Adapter (Rear clutch drum)
	AT-93-3	2.42	Adapter (Oil delivery sleeve)
	AT-93-4	1.90	Adapter (Front drum bushing)
	AT-93-5	5.00	Adapter (Reverse Internal Gear Bushing)
	AT-93-6	2.13	Driver Handle
SET NO. AT-94	AT-94-1	2.60	Adapter (Rear pump bushing)
	AT-94-2	2.70	Driver Handle
	AT-94-3	1.27	Adapter (Rear clutch sun Gear)
	AT-94-4	1.32	Adapter (Rear clutch sun Gear)
	AT-94-5	1.45	Adapter (Rear clutch sun Gear)
	AT-94-6	1.27	Adapter (Pinion Carrier)
	AT-94-7	1.67	Adapter (Output Shaft)
	AT-94-8	2.07	Adapter (Front Pump Bushing)
	AT-94-9	1.55	Adapter (Case Bushing)

Board Number	Price	Description
DB-21	$159.57	Internal Auto Transmission Tools
DB-23	147.89	External Automatic Transmission Tools
TBF-1	65.93	Display Board, including the following tools: AT-52, AT-53, AT-25, AT-22 AT-23, AT-24, AT-71 and AT-7
TBG-2	64.43	Display Board, including the following tools: AT-5, AT-6, AT-20, AT-21, AT-50, AT-51, AT-54 and AT-70